



INSTALLATION INSTRUCTIONS

ISP PLUG-IN INTRINSICALLY SAFE RELAYS

SERIES A

December, 2007 Rev A

901-0000-260

READ INSTRUCTIONS BEFORE INSTALLING OR OPERATING THIS DEVICE. KEEP FOR FUTURE REFERENCE.


Warning

Potentially hazardous voltages are present. Turn off all power supplying this equipment before connecting or disconnecting wiring.

Installation & Setup

1. Mount the unit in a suitable enclosure in a non-hazardous area. Only use the 8 pin octal socket that was supplied with the relay.
2. Connect wiring per Macromatic's Control Drawing ISR2A01D (below). Follow all hazardous code requirements while installing wiring to switch input terminals.

UL Control Drawing ISR2A01D



Notes:

1. All intrinsically safe wiring shall be separated from non-intrinsically safe wiring. Refer to Article 504 of the National Electrical Code (ANSI/NFPA 70) for installation of intrinsically safe wiring.
2. Maximum distance between unit and switch contacts is 1,000 feet.
3. Switch contact shall be any non-energy storing or generating switch type device containing no capacitance or inductance.
4. Device must be installed in Omron socket PF083A and with locking clips attached to base.
5. Cable capacitance plus intrinsically safe equipment capacitance (C_i) must be less than the marked capacitance (C_a). Cable inductance plus intrinsically safe equipment inductance (L_i) must be less than the marked inductance (L_a) shown on any associated apparatus used.
6. The simple apparatus (float switch) connected to the ISR shall not be mounted on other electrical apparatus that has a voltage and current rating higher than the ISR (see Entity Parameters V_{oc} & I_{sc} below). A simple apparatus (such as a float switch) is defined as an electrical component or combination of components of simple construction with well defined electrical parameters that does not generate more than 1.5V, 100mA and 25mW, or a passive component that does not dissipate more than 1.3W and is compatible with the intrinsic safety of the circuit in which it is used.
7. If the electrical parameters of the cable are unknown, then a capacitance of 60 pF/ft and an inductance of 0.20 uH/ft are to be used. Cable capacitance and cable inductance are calculated as follows:

$$60\text{pF/ft} \times 100 = 6.0\text{nF}$$

$$0.2 \mu\text{H/ft} \times 100 = 20\mu\text{H}$$

8. Entity Parameters: $V_{oc} = 9.33\text{V}$ $I_{sc} = 0.218\text{mA}$ $C_A = 3.6\mu\text{F}$ $L_A = 100\text{mH}$

Warranty--All intrinsically safe products offered by Macromatic are warranted to be free from defects in workmanship or material under normal service and use for a period of Five (5) Years from date of manufacture.