

## ORDER CODES

### SOFT STARTERS



ADXL 0018 600 ... ADXL 0060 600



ADXL 0075 600 ... ADXL 0115 600



ADXL 0135 600 ... ADXL 0162 600



ADXL 0195 600 ... ADXL 0320 600

Rated operational voltage  $U_e$ , 208...600VAC  $\pm$  10%.  
Rated control supply voltage  $U_s$ , 100...240VAC.

Order code	Rated starter current $I_e$ [A]	IEC rated motor power			FLA [A]	UL508 rated motor power				
		230 VAC [kW]	400 VAC [kW]	500 VAC [kW]		208 VAC [HP]	220/240 VAC [HP]	380/415 VAC [HP]	440/480 VAC [HP]	550/600 VAC [HP]

For standard and heavy-duty applications. With built-in bypass relay. 100...240VAC auxiliary power supply. Start control from dry contact.

ADXL 0018 600	18	4	7.5	11	18	5	5	10	10	15
ADXL 0030 600	30	7.5	15	18.5	28	10	10	15	20	25
ADXL 0045 600	45	11	22	30	44	10	15	25	30	40
ADXL 0060 600	60	15	30	37	60	20	20	30	40	50
ADXL 0075 600	75	22	37	45	75	25	25	40	50	60
ADXL 0085 600	85	22	45	55	83	25	30	50	60	75
ADXL 0115 600	115	37	55	75	114	40	40	60	75	100
ADXL 0135 600	135	37	75	90	130	40	50	75	100	125
ADXL 0162 600	162	45	90	110	156	50	60	75	125	150
ADXL 0195 600	195	55	110	132	192	60	75	100	150	200
ADXL 0250 600	250	75	132	160	248	75	100	150	200	250
ADXL 0320 600	320	90	160	200	320	100	125	200	250	300

### ACCESSORIES



CX 01



CX 02



EXC RDU1



EXC 1042



EXC CON 01



EXC M3G 01



EXP80 03



EXA 01



EXA 02



EXA 03



EXA 04

Order code	Description
CX 01	USB connection dongle PC $\leftrightarrow$ ADXL for programming, monitoring, diagnostics and firmware update
CX 02	Wi-Fi connection dongle PC $\leftrightarrow$ ADXL for programming, monitoring, diagnostics and cloning
EXC RDU1	Remote display unit, LCD graphic display with touchscreen, for monitoring and control of max 32 drives, IP65 and 4X, built-in RS485 port, 3m long cable included
EXC 1042	RS485 communication card
EXC CON 01	RS485/Ethernet converter, 12...48VDC, including DIN mounting guide kit
EXC M3G 01	RS485 gateway/3G modem, 9.5...27VAC/9.5...35VDC, including antenna and programming cable
EXP80 03	DIN guide mount kit for ADXL 0018 600...ADXL 0115 600
EXP80 04	Fan for ADXL 0018 600...ADXL 0115 600 (codes ADXL 0075 600...ADXL 0115 600 max. of two EXP80 04 fans)
EXA 01	Kit of 3 terminal lugs UL for ADXL 0135 600, ADXL 0162 600, ADXL 0195 600
EXA 02	Kit of 3 terminals protection for ADXL 0135 600, ADXL 0162 600, ADXL 0195 600
EXA 03	Kit of 3 terminal lugs UL for ADXL 0250 600 and ADXL 0320 600
EXA 04	Kit of 3 terminals protection for ADXL 0250 600 and ADXL 0320 600